



FujiFilm FinePix S5100 Battery Replacement

The replacement guide will show you how to replace the batteries on a Fujifilm FinePix S5100 camera.

Written By: Evans



INTRODUCTION

This replacement guide will show you how to replace the batteries in a Fujifilm FinePix S5100 camera.

You will need 4 AA Alkaline or Lithium batteries. Be sure to properly dispose of or recycle your batteries in accordance with your state law.

Step 1 — Battery



⚠ Ensure your camera is in the off position.


- Orient the camera upside down with the lens facing to the left and the battery compartment facing directly toward you.

Step 2



- Open the battery door by pushing down and in the direction of the arrow on the door.

Step 3



- Remove four AA batteries from the camera.

To reassemble your device, follow these instructions in reverse order.