



Fujifilm FinePix S1 Flash Spring Replacement

Replace the spring for the pop-up flash compartment.

Written By: Brandon Benavente



INTRODUCTION

Following this guide involves simple removal of the pop-up flash casing, keeping the rest of the camera intact.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [JIS Driver Set](#) (1)
-

Step 1 — Flash Spring



- Remove the 4 screws from the flash casing.

Step 2



- Pry the edges off of the flash casing, and pull it off of the camera.

Step 3



- Locate the spring on the left-hand side of the camera.
- Remove the spring by pulling it out of its placement.

To reassemble your device, follow these instructions in reverse order.