



Fujifilm X100T Battery Replacement

This guide will show you how to replace the rechargeable battery pack for the Fujifilm X100T camera.

Written By: Christian Johansen



INTRODUCTION

Follow the following steps to replace a discharged or broken battery.

Step 1 — Battery



- Slide the small black tab on the bottom of the camera to the left to unlock the battery cover.

Step 2



- Push the orange tab up to release the battery.
 - Slide the battery out of the camera.
- (i)** Invert the camera to slide out the battery more easily.

To reassemble your device, follow these instructions in reverse order.