





Fusion5 5.5 Gen II Back Cover Replacement

How to replace the back cover of a Fusion5 5.5 Gen II.

Written By: Kristen Gismondi



Step 1 — Back Cover



- Hold the device with the screen facing away from you and the back of the device facing you.
- Locate the groove at the bottom corner of the device.
- Begin prying the back cover of the device off from the groove and working your way around the outside edges of the device.

To reassemble your device, follow these instructions in reverse order.