



GPD WIN Joystick Locker Cap Replacement

Is your GPD Win Joystick dirty? It can be fixed!

Written By: noria901



INTRODUCTION

The Joystick on the GPD Win is known to get dirty to the point where it can become hard to use, so let's replace the Locker cap



PARTS:

- New Item (1)

Step 1 — Joystick Locker Cap



- Use force to remove the end of the locker cap on the joystick.
- Install the new locker cap where the old one used to be.

To reassemble your device, please follow these steps in reverse order.