




Game Boy Advance Back Panel Replacement

Written By: Aldo Corona



INTRODUCTION

How to remove the back panel from a Game Boy Advance.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
- [Tri-wing Screwdriver](#) (1)

Step 1 — Battery



- Take the battery cover off by releasing the locking tab and hinging the cover away.

Step 2 — Back Panel




- Remove the six back panel screws using a Tri-wing Screwdriver.

Step 3



- Remove bottom back panel screw with a Phillips #1 screw driver.

Step 4



- Remove the back panel by pulling away with one hand and the front secured in the other hand.

 Removal of the back panel may cause shoulder buttons and side panels to come loose and fall off.

To reassemble your device, follow these instructions in reverse order.