




Garmin Nuvi 1390LMT Touch Screen Replacement

This guide will show you how to replace the touch screen on a Garmin Nuvi 1390LMT.

Written By: Trey Ulsh



INTRODUCTION

This guide will show you how to disassemble the Garmin Nuvi 1390LMT GPS to replace the touch screen.



TOOLS:

- [T5 Torx Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Touch Screen



- Snap the plastic cover off using a plastic opening tool.

Step 2



- Remove the four black 11 mm T5 torx screws.

Step 3



- Pop the screen cover off with a plastic opening tool.

Step 4



- Gently pull the wire ribbon connecting the screen to the logic board from the plug.

⚠ Be careful when unplugging the wire ribbon. It is very fragile.

To reassemble your device, follow these instructions in reverse order.