



# Garmin Nuvi 255W Power Button Replacement

Installing a new Power Button for the Garmin Nuvi 255W.

Written By: Timothy



## INTRODUCTION

If your power button is defective, replace the old one with the new power button.

### TOOLS:

- T5 Torx Screwdriver (1)
- iFixit Opening Tools (1)

### PARTS:

- new Garmin Nuvi 255W power button (1)

## Step 1 — Power Button



- Remove the barcode sticker at the bottom of the device.

## Step 2



- Remove two 8.4 mm T5 screws from the bottom of the device.


## Step 3



- Using a plastic opening tool, carefully pry open the device.

**⚠** Open the device carefully, making sure not to damage the gold ribbon cable that connects the screen to the motherboard.

## Step 4



- Remove the power button.

To reassemble your device, follow these instructions in reverse order.