



Garmin Nuvi 265WT Screen Replacement

Written By: Patricia Gonzalez



 **TOOLS:**

- [Spudger \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [P2 Pentalobe Screwdriver \(1\)](#)

Step 1 — Screen



- Remove PN/Model sticker an the lower side of the device.
- Use pentalobe screwdriver to remove the two screws underneath it.
- Use the nylon spudger to remove the screen from the device.

 The regular black nylon spudger should be used whenever possible, especially around glass displays and other sensitive components.

Step 2




- Lift up the screen gently and place it on the opposite side.

Step 3



- Use a plastic opening tool to gently lift up the white rectangular snap clip that is attached to the screen.

Step 4



- Lift up the screen and you're done.

To reassemble your device, follow these instructions in reverse order.