



Garmin Vivoactive HR Wrist Band Replacement

Replacement guide for broken or interchangeable wrist bands. Garmin Vivoactive Hr wrist band replacement.

Written By: David Myrick



INTRODUCTION

Replacement wrist bands can be purchased to either change the color of the bands or repair broken components.

TOOLS:

- [T4 Torx Screwdriver](#) (1)

Step 1 — Wrist Band



- Using a T4 Torx driver, remove the 4.34mm screw from band post.
(i) You will need to hold in the screw on the other side in order to remove the screw for the band
- Remove the post from band and remove the band.

Step 2



- Repeat step 1 on the second watch band.

To reassemble your device, follow these instructions in reverse order.