



# Gateway 600YGR Battery Replacement

This guide will take you through the steps of replacing your device's battery.

Written By: Brent Bachelor



## INTRODUCTION

This guide provides the step by step directions for removing and replacing the battery for a Gateway 600YGR. There are no prerequisite guides that need to be completed in order to use this guide. No tools are required to complete this guide.



## PARTS:

- [Gateway 600YGR battery \(1\)](#)

## Step 1 — Battery



- Flip your computer over so that the bottom of your device is face up.

## Step 2



- Locate the slide indicated in red and slide it to the right.
- Lift the battery at the indent indicated in orange.

☞ For Battery Re-instillation, place battery in opening and push down until a click is heard.

## Step 3



- Remove the Battery.

To reassemble your device, follow these instructions in reverse order.