



Gateway LT2514u Battery Replacement

Use this guide to replace the battery on the Gateway LT2514u.

Written By: Brian Garver




INTRODUCTION

This guide will walk you through the process of replacing a dead or dying battery in a Gateway LT2514u.

TOOLS:

- [Tweezers \(1\)](#)

Step 1 — Battery



- With the netbook's lid closed, flip it over and slide the latch on the upper left hand side of the netbook to the left.
- (i)* You should see an orange indicator when the battery is unlocked.

Step 2



- In the upper right-hand corner of the netbook, slide and hold the switch to the right.
- Use your other hand to slide out the battery.

(i) If the release switch in the upper right-hand area is missing, you can still remove the battery by following Step 3. Otherwise, skip it.

Step 3



- If the release switch in the upper right-hand area is missing, insert a slender tool (we used tweezers) into the left side of the smaller hole.
- Slide and hold the tweezers to the right and use your other hand to slide the battery out.

To reassemble your device, follow these instructions in reverse order.