Gateway MD2614u Internal Modem Replacement

This guide will instruct you on replacing the internal modem

Written By: Nelson

This document was generated on 2020-03-11 11:10:46 PM (MST).

© iFixit — CC BY-NC-SA | www.iFixit.com | Page 1 of 6

🔧 TOOLS:

- Spudger (1)
- Large Needle Nose Pliers (1)
- Phillips #00 Screwdriver (1)

Step 1 — Back Cover

- Place the laptop so the back cover is facing up.

Step 2

- Remove the 8 screws from the back cover using the Phillips #00 screwdriver.

This document was generated on 2020-03-11 11:10:46 PM (MST).

Step 3

- Lift off the cover.

Step 4 — Internal Modem

- The internal modem will be located towards the bottom right of the laptop (highlighted with a yellow square).

This document was generated on 2020-03-11 11:10:46 PM (MST).

Step 5

- Using a Phillips #00 screwdriver, unscrew both of the screws that are holding the modem in place.

Step 6

- Carefully pry the modem as to not damage any of the surrounding components

Step 7

- Using needle nose pliers, carefully detach the wire connecting the modem, by applying pressure to the black tabs away from the modem itself.

Step 8

- Success! You've removed the internal modem!

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-03-11 11:10:46 PM (MST).