



Gateway NV57H50u Hard Drive Replacement

This guide will show how to remove and replace the Gateway NV57H50u hard drive.

Written By: Aaron Allison



This document was generated on 2019-10-14 07:58:34 PM (MST).

INTRODUCTION

Both the battery and rear cover guides should be completed before completing this guide. This guide can be used for replacing a dying hard drive or upgrading your current hard drive.

TOOLS:

- [Spudger](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Battery



- Push orange locking tab with spudger right, until battery lifts out of place.

⚠ Laptop should be unplugged from power supply before removal.

Step 2 — Rear Cover



- Unscrew the two 7 mm long #0 Phillips screws.

Step 3



- Lift and remove the cover panel via the indentation in the middle of the panel.

Step 4 — Hard Drive



- Push spudger to the left until hard drive is moved from its original position.

Step 5



- Pull plastic flap and pull hard drive away from laptop.

To reassemble your device, follow these instructions in reverse order.