



# GoPro Hero3+ Black Edition Battery Replacement

This guide will illustrate how to access and remove the battery for the GoPro Hero3+ Black Edition.

Written By: Chad Carlson



## INTRODUCTION

Can't seem to charge your battery? It may be time to replace it. This guide will walk you through the simple steps to access and replace your GoPro battery.



## PARTS:

- [GoPro Hero3/3+ Replacement Battery](#) (1)
- [GoPro Hero3/3+ AHDBT-301 Battery](#) (1)
- [GoPro Hero3/3+ AHDBT-302 Battery](#) (1)

## Step 1 — Battery



- Pull the tab on the back of the device to release the back cover. It should come right off.
- *(i)* The device pictured does not include the back cover.

## Step 2



- Use the battery tab to pull the battery out of the device.

## Step 3



- Remove the battery from the slot.

To reassemble your device, follow these instructions in reverse order.