




# Google Pixel 3a Battery Disconnect

Prerequisite guide only! Battery disconnect step for the Pixel 3a.

Written By: Arthur Shi




## INTRODUCTION

Prerequisite guide only! Battery disconnect step for the Pixel 3a.

### TOOLS:

- [Spudger \(1\)](#)

## Step 1 — Google Pixel 3a Battery Disconnect



- Use the point of a spudger to pry up and disconnect the battery connector from its motherboard socket.
- Bend the battery flex cable slightly so that it will not accidentally make contact with the socket.

To reassemble your device, follow these instructions in reverse order.