




# Gotrax Hover board Charging port Replacement

This guide will show how to replace the charging port and power button on a hover board.

Written By: Haden Kuta




 **TOOLS:**

- Phillips #1 Screwdriver (1)

 **PARTS:**

- aokur Smart Balancing Hoverboard Charging Port Power Button Repair Parts (1)

## Step 1 — Take apart



- First determine which side of the board has the power button and charging port on it. Then remove the bottom cover of the board by unscrewing the 10 screws on the power button side.

## Step 2 — Unplug



- Once you remove the cover unplug the charging port, power button, and LED light to make it easier to work on.

### Step 3 — Out with the old



- Once the cover is completely detached unscrew the nut on the back of the charging port and power button that is securing it in its place. To remove the charging port and power button push them through front of the cover.

To reassemble your device, follow these instructions in reverse order.