



Graco Snugrider Elite Front Wheel Replacement

If there are any problems occurring with the front wheel, follow this guide so you can take it off to either repair it or replace it.

Written By: Paul Studer



This document was generated on 2019-09-22 11:58:52 AM (MST).

INTRODUCTION

This guide will demonstrate how to replace the plastic front wheels of the Graco Snugrider Elite. If the connection between the wheel and the leg malfunctions, be prepared to reinstall the front wheel by utilizing the button.

Step 1 — Front Wheel



- Press down on the grey button located just above the wheel.

Step 2



- While still holding the grey button, pull the wheel off.

(i) It might help to put your other hand on the base of the stroller to help keep the stroller in place.

To reassemble your device, follow these instructions in reverse order.