



# HP 15 Series Battery Replacement

This guide teaches you how to replace the battery in an HP 15 Series laptop.


Written By: Joseph Sctbunio



## INTRODUCTION

This guide teaches you how to replace the battery in an HP 15 Series laptop.

## Step 1 — Remove the battery



- Move both tabs towards the center of the laptop. The battery will come out.
- Putting in a new battery is as simple as sliding it back in the way the old one came out. You're done!

To reassemble your device, follow these instructions in reverse order.