



# HP 15-ay014dx Optical Drive Replacement

This guide will show you how to replace your optical drive

Written By: Colton King



## INTRODUCTION

This guide will show you how to easily replace your optical drive.

### TOOLS:

- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Battery



 Disconnect device from power source and power down.

## Step 2



- With the device turned upside down, use your index fingers to push the battery latches in towards each other.

## Step 3



- ⓘ The latch on your left will stay at the inward position, while the latch on the right will slide back out.
- Gently grasp the battery and pull it back away from the device and yourself.

## Step 4 — Optical Drive



- Close the laptop and lay it down with the bottom facing up.
- Using a size #00 Phillips screw drive remove the screw holding in the optical drive.

## Step 5



- Grip the optical drive and gently pull it out.

To reassemble your device, follow these instructions in reverse order.