HP 15-ay103dx Battery Replacement

This guide will walk you through the process of replacing the battery on the HP 15-ay103dx.

Written By: Daymon Brisco

www.iFixit.com

Step 1 — Battery

- Slide the two battery lock latches on the back of the device to the "unlock" position.

Step 2

- Lift the battery upward to remove it from the device.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-10-27 11:51:31 PM (MST).