



# HP 15-ba0709dx Battery Replacement

This guide details how to replace the battery on an HP 15-ba0709dx. If your laptop does not stay on, shuts off, or won't charge, this is the guide for you.

Written By: Reece Marr



## INTRODUCTION


Follow this guide to remove the battery of a HP 15-ba0709dx laptop. This repair may be needed if your battery is not holding a charge.

## Step 1 — Battery



- Flip the device over and locate the battery compartment.
- Slide the battery release latch on the left and right side until the battery is detached from its slot.
- A noticeable pop will be heard when the battery is fully released.

## Step 2



- Pull the battery out of its slot.

**⚠** Be careful not to damage any of the connectors in the process.

To reassemble your device, follow these instructions in reverse order.