



HP 15-g010dx Keyboard Replacement

This guide will show you step by step instructions on replacing the keyboard.

Written By: Christopher



INTRODUCTION

If your keyboard isn't responding, then you can replace it by using this guide. It is recommended that you have the tools suggested in this guide ready to use. Make sure that you follow the prerequisite guide and remove the battery before attempting.

TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Metal Spudger](#) (1)

Step 1 — Battery



- Slide the latch towards the center of the laptop so the unlock emblem appears.

Step 2



- Place your finger on the left latch and slide it towards the center of the laptop.

Step 3

- Pull on the battery to remove.




Step 4 — Keyboard

- Remove the two 5 mm screws with the Phillips #00 screwdriver.




Step 5



- Using either a credit card or flat spudger, wedge it between the palm rest and the keyboard.

Step 6




- Using the tool of your choice, gently pry up on the top of the keyboard.

Step 7



- Release the top of the keyboard.

Step 8



- Remove the ZIF connector that connects the laptop to the keyboard cable.

To reassemble your device, follow these instructions in reverse order.