



HP 15-g020dx Battery Replacement

Use this guide to replace the battery in your HP 15-g020dx.

Written By: Yisong Zou



INTRODUCTION

Is your battery dying often? Does it not hold charge or even not charge at all? Well maybe it's time to replace your battery and with this guide you can replace it taking 5-10 minutes of your time. Follow this guide to successfully remove the battery from your laptop.

This guide will walk you through step by step on how to replace the battery. Is the battery on your computer not working and you found out it costs a lot to have them fixed? Well you are in luck. The following guide consists of the steps to remove the battery from the computer while also showing you the pre-requeste steps to be able to remove the battery. This guide allows you to replace your battery yourself for free rather than having to pay someone to do it.

Step 1 — Battery



- Flip the laptop over so that the bottom is facing you.
- Slide the latch towards the center of the laptop so the unlock emblem appears.

Step 2



- Place your finger on the left latch and slide it towards the center of the laptop to remove the battery.

Step 3

- Remove the battery from the laptop.



To reassemble your device, follow these instructions in reverse order.