



HP 15-g020dx Keyboard Replacement

Use this guide to replace the keyboard in your HP 15-g020dx.

Written By: Yisong Zou



INTRODUCTION

If your keyboard isn't responding, then you can replace it by using this guide. It is recommended that you have the tools suggested in this guide ready to use. This guide will walk you through step by step on how to replace the keyboard. Is the keyboard on your computer not working and you found out it costs a lot to have them fixed? Well you are in luck. The following guide consists of the steps to remove the keyboard from the computer while also showing you the pre-requeste steps to be able to remove the keyboard.

TOOLS:

- iFixit Opening Tools (1)

Step 1 — Battery



- Flip the laptop over so that the bottom is facing you.
- Slide the latch towards the center of the laptop so the unlock emblem appears.

Step 2



- Place your finger on the left latch and slide it towards the center of the laptop to remove the battery.

Step 3

- Remove the battery from the laptop.



Step 4 — Keyboard

- Use the plastic opening tool to lift the panel with the keyboard.




Step 5



- Take the keyboard and the section of the panel surrounding the keyboard apart.

Step 6



- Lift the flip covering the connection port and remove the connecting strip to detach the keyboard from the motherboard.

To reassemble your device, follow these instructions in reverse order.

