



HP 15-g020dx Optical Drive Replacement

Use this guide to replace the optical drive in your HP 15-g020dx.

Written By: Haimeng Zhang



INTRODUCTION

Is your DVD-ROM cracked or smashed? Or it can not open? Well, you are in luck, this replacement guide will help aid you replace the DVD-ROM. This guide is helpful if the DVD-ROM doesn't work.

This guide will walk you through step by step on how to replace the DVD-ROM. Is the DVD-ROM on your computer not working and you found out it costs a lot to have them fixed? Well you are in luck. The following guide consists of the steps to remove the DVD-ROM from the computer while also showing you the prerequisite steps to be able to remove the DVD-ROM. This guide allows you to replace your DVD-ROM yourself for free rather than having to pay someone to do it.

TOOLS:

- Phillips #0 Screwdriver (1)

Step 1 — Optical Drive



- Flip over the device so that the bottom is facing you.
- Remove the screws using the Phillips #0 screwdriver.

Step 2



- Drag the optical drive horizontally until it detaches from the port on motherboard.
- Remove the optical drive from the device.

To reassemble your device, follow these instructions in reverse order.