




HP 15-g071nr Hard Drive Replacement

This guide will show how to safely replace a hard drive in an HP 15-g071nr Laptop.

Written By: Emerson Tatelbaum



INTRODUCTION

Is your computer running too slow and you want to replace your hard drive with an SSD or one with more RPMs? Then this is the guide for you! Replacing the hard drive in an HP 15-g071nr laptop is easier than you may think, so do not be intimidated. NOTE: Turn off laptop before starting this guide.

TOOLS:

- [iFixit Opening Tools](#) (1)
- [Phillips #0 Screwdriver](#) (1)

Step 1 — Battery



- Flip the laptop over.
- ⓘ Accessing the device's battery requires no tools.

Step 2



- Press the tabs at the corners of the laptop at the same time, this will release the battery.

Step 3



- Pull the battery away from the laptop in one motion.

Step 4 — Hard Drive



- Using your Phillips #0 screwdriver, remove all of the screws on the back case.

Step 5



- Carefully move the iFixit opening tool along the seam of wrist rest until you can remove it.
- Remove the wrist rest once it comes loose from the body.

Step 6



- Remove the two screws with the Phillips #0.
- Gently pull the hard drive out of its SATA connection to the motherboard.
- Attach the loose data cable to the new drive.

 Be careful not to damage the silver ribbon cable below the hard drive itself.

To reassemble your device, follow these instructions in reverse order.