



HP 17-x027ds Keyboard Key Replacement

How to replace an HP 17-x027ds keyboard key.

Written By: Tyrin



INTRODUCTION

This guide shows how to extract a key from the laptop.

TOOLS:

- Metal Spudger (1)

Step 1 — Keyboard Key



- Use a metal spudger or your fingernail to extract the key.

To reassemble your device, follow these instructions in reverse order.