



# HP 17-x116dx Battery Replacement

In this guide we will be replacing the battery on the HP17-x116dx laptop.

Written By: Sarah Coral



## INTRODUCTION

The battery is essential for a laptop. Without the battery you will not be able to operate your computer. This guide will show you how to replace the battery.

## Step 1 — Battery



- Turn off your computer before starting. Place the back of your computer face up to ensure you are facing the battery.

## Step 2



- Find the battery latches.
- Slide the latches towards the center of the device.

## Step 3



- Remove the old battery by pulling it towards you. Replace the old battery with the new one and follow these steps in reverse order to reassemble your device.

To reassemble your device, follow these instructions in reverse order.