HP 8 1401 Back Panel Replacement

In this guide, you will learn how to remove the back panel of your HP tablet.

Written By: Katie Presz

INTRODUCTION

This guide is useful if you need to replace any of the parts inside the device. When moving the opening tool around the device, it might be necessary to pull a little to detach the two sides.

🔧 TOOLS:

- iFixit Opening Tools (1)
- T4 Torx Screwdriver (1)

This document was generated on 2019-10-20 02:06:35 PM (MST).

Step 1 — Back Panel

- Using a Torx T4 screwdriver, remove the four 5 mm screws on the back panel.

Step 2

- Insert the tip of a plastic opening tool in the seam between the front and back panels.

This document was generated on 2019-10-20 02:06:35 PM (MST).

© iFixit — CC BY-NC-SA

www.iFixit.com

Page 3 of 4

Step 3

- Slide the plastic opening tool around all edges of the device until the back panel detaches.

- Lift off the back panel.

To reassemble your device, follow these instructions in reverse order. Align the front and back panels and press them together, then screw in the four screws.