



HP Compaq 6515b Battery Replacement

This guide will show you how to replace the battery in your HP Compaq 6515b.

Written By: Thomas Sirack



INTRODUCTION

This guide will show you how to replace the battery in your HP Compaq 6515b.



TOOLS:


- Fingers (1)



PARTS:

- [HP Compaq 6515b Battery](#) (1)

Step 1 — Battery



- Push the two battery release latches to the left.
- Push out the battery with the raised area.

To reassemble your device, follow these instructions in reverse order.