



HP EliteOne 800 G1 Removing the Back Cover Replacement

Prerequisite Only

Written By: Kyle Koivuniemi



This document was generated on 2019-10-01 03:10:54 PM (MST).

INTRODUCTION

This step is the starting point of all the guides for this product. Keep track of all parts removed in this guide to ensure the device functions properly at the end.

Step 1 — Removing the Back Cover



- Place computer with the screen down on a flat surface.
- Push the two locking latches to the unlocked position.
- Push the cover toward the top of the computer and lift up.

To reassemble your device, follow these instructions in reverse order.