




# HP Envy Touchsmart m6-k125dx RAM Replacement

Use this guide to replace your RAM for a memory upgrade.

Written By: Alec Stensland



## INTRODUCTION


Use this guide to replace your RAM for a memory upgrade that can provide enhanced multitasking abilities and overall improve your laptop's performance. The RAM is a very important component to any computer, because it stores loads of data.



### TOOLS:


- [JIS #000 Screwdriver](#) (1)
  - [Phillips #000 Screwdriver](#) (1)
-

## Step 1 — Back Panel



- Turn the laptop over so that the bottom is facing up
- Using the J0 screwdriver, unscrew all 12 M2.5x5.5 screws from the back panel.


## Step 2



- Carefully remove the back panel to reveal the inner components.





## Step 3 — RAM



- Locate both of the RAM devices and choose which one will be replaced.

## Step 4



- Gently remove the RAM by pressing against the side clamps of the connector holding it in place.

To reassemble your device, follow these instructions in reverse order.