



HP Envy dv6-7363cl Battery Replacement

This is a guide showing how to replace the battery of your HP Envy dv6-7363cl.

Written By: dylananthony



INTRODUCTION

Reader will be able to successfully replace their battery in the device. Charging cable must be unplugged from device before attempting.



PARTS:

- HP TouchPad Battery (1)

Step 1 — Battery



- Flip the device upside-down so that its bottom is facing up.

Step 2



- Push the lever underneath the battery to the left as shown in the picture.

Step 3



- Lift the battery up out of its socket.

To reassemble your device, follow these instructions in reverse order.