




# HP Envy m6-p114dx Back panel

This guide will show you step one on disassembling the Hp envy m6-p114dx by removing the back panel to see the internal hardware.

Written By: Taylor Cheney



## INTRODUCTION

This guide will show you the step by step instructions on disassembling the Hp envy m6-p114dx by removing the back panel to see the internal hardware.

This step is needed for anything that requires access to the internals of the device.

### TOOLS:


- [Phillips #1 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)

## Step 1 — HP Envy m6-p114dx Back panel



- Power the device off, unplug it, and ground yourself.

## Step 2



- Remove the twelve screws in the back case using a Phillips #1 screwdriver.

## Step 3



- Carefully wedge an iFixit opening tool under the cover and slide it alongside the case to ensure that all clips are un-clipped.