




HP Envy x2 13-j002dx Screen Replacement

Learn how to replace the screen on your HP Envy x2 13-j002dx tablet with just a few simple steps.

Written By: Colton Moon



INTRODUCTION

In the device HP Envy x2 13-j002dx , you will be replacing the screen with one step. Prior to removing and replacing the screen, it will be important to remove the battery and the motherboard. You can see how to remove the battery and motherboard in Steps 1-13. Once you follow the steps presented in the guide, you should be met with little to no resistance when removing the screen.

TOOLS:


- [Phillips #0 Screwdriver \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)
- [iFixit Opening Tools \(1\)](#)
- [Magnetic Project Mat \(1\)](#)
- [Tweezers \(1\)](#)
- [iFixit Opening Picks set of 6 \(1\)](#)

Step 1 — Battery



- Remove five 4mm Phillips #0 screws securing the lower case to the HP Envy x2 13-j002dx.

Step 2




- Use a Phillips #00 screwdriver to remove the two 3.5 mm screws from the bottom of the device—one on each side of the keyboard dock.

Step 3




- Use a pair of tweezers to remove the screw covers on the bottom of the device.
- Use a Phillips #0 screwdriver to remove the two 4mm screws.

Step 4




- Use an opening pick to remove the plastic cover above the back stand.
- Pry the cover off.
- Use a Phillips #0 screwdriver to remove the four 4 mm screws.

Step 5




- Use an opening pick and a prying tool, and go around the device to remove the back cover from the rest of the assembly.

Step 6




- Unplug the battery from the motherboard.

Step 7




- Carefully pull up on the battery connector from the speaker.
- Use a pair of tweezers and remove the taped down wire for the speaker.
- Use a Phillips #00 screwdriver to remove the seven 3mm screws around the battery.

Step 8





- Carefully lift up and remove the battery.

Step 9 — Motherboard





- Before removing the motherboard, clear away any dust, and ensure that the battery is already removed.

Step 10




- Using a Phillips #0 screwdriver, remove the three 3.8 mm screws along the edge of the motherboard.

Step 11




- Disconnect the cable connectors from the motherboard. This can be done with either tweezers or with your fingers.

Step 12




- Using the Phillips #0 screwdriver, remove the 3.2mm screws within the copper rings in the circuit board.
- Using the Phillips #0 screwdriver, remove the 2.5mm and 4.25mm black screws on the motherboard.

Step 13



- Once the screws and cables are disconnected and removed, remove the motherboard from the frame.

Step 14 — Screen



- Once the battery and motherboard are removed, the screen unit should offer little resistance. Remove the screen from the base.

To reassemble your device, follow these instructions in reverse order.