



HP Envy x360 15-bp143cl Screen Replacement

How to replace the screen on an HP Envy x360 15-bp143cl laptop.

Written By: Spencer Berkins



INTRODUCTION

Use this guide to replace the screen of an HP Envy x360 15-bp143cl. The laptop is also identified by its model number, 3TS71UAR#ABA.


Many factors can cause a laptop's screen to malfunction or break. Review the [HP Envy x360 15-bp143cl Screen Troubleshooting Page](#) to check if any common factors are affecting the performance of your device.

Turn the laptop off and disconnect it from any power supply before starting the replacement process.

TOOLS:

- [Suction Handle \(1\)](#)
- [iFixit Opening Tools \(1\)](#)


Step 1 — Screen



- Use a suction handle to pull the screen display out of the screen casing.

i If the screen is difficult to remove, use an opening tool to pry the sides of screen from the screen casing.

Step 2



- Lift the screen display from the screen casing, hinging it from the top edge to expose the back of the panel.

⚠ Do not separate the display from the casing completely, as there are still cable connections holding it in place.

Step 3



- Detach the connecting cable between the laptop and the display screen.
- Remove the display screen.

To reassemble your device, follow these instructions in reverse order.