



HP Mini 110-3131dx Back Cover Replacement

Removing the back cover of HP Mini 110-3131dx.

Written By: aarondcollege




Step 1 — Battery



- Completely turn off the laptop before trying to remove the battery.
- Turn the laptop upside down, and find the sliding tabs located on the battery.
- Slide both tabs in an inward direction then slide the battery away from the laptop

Step 2 — Back Cover



- To remove the bottom cover pull the orange tab to the right until it clicks.
- Carefully disconnect the clips as you lift the bottom cover

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2019-09-18 10:45:32 PM (MST).

