



HP Mini 110-3131dx Battery Replacement

Replace the dead battery to power up your HP Mini 110-3131dx notebook.

Written By: aarondcollege

Step 1 — Battery



- Completely turn off the laptop before trying to remove the battery.
- Turn the laptop upside down, and find the sliding tabs located on the battery.
- Slide both tabs in an inward direction then slide the battery away from the laptop

To reassemble your device, follow these instructions in reverse order.