



# HP Mini 210-1035la Keyboard Replacement

Use this guide to replace the keyboard on your HP Mini 210-1035la.

Written By: Internet Libre



## INTRODUCTION

Use this guide to replace the keyboard on your HP Mini 210-1035la.

### TOOLS:

- Pro Tech Toolkit (1)

## Step 1 — Keyboard




- Shut down the computer
- Remove the battery.

## Step 2 — Rubber feet



- Remove the 4 rubber feet

## Step 3 — Removing service cover



- Simultaneously press in on the right release button (1) and release the right side of the service cover (2)
- Simultaneously press in on the left release button (3) and release the left side of the service cover (4)

*ⓘ Reverse this procedure to insert the service cover*

## Step 4 — Keyboard's screws



- Remove the three screws that hold the keyboard
- With the computer front toward you, turn it right-side up.
- Completely open the computer

## Step 5 — Remove keyboard



- Lift the back edge of the key board until it rest at an angle
- Slide the keyboard back until the keyboard cable and connector are accessible
- Release the connector to which the keyboard cable has been attaching, and then disconnect the keyboard cable
- Remove the keyboard

To reassemble your device, follow these instructions in reverse order.