



# HP Officejet Pro 8620 Power Button Replacement

This guide will show you how to replace the power button for the HP Officejet Pro 8620.

Written By: Scott



## INTRODUCTION

The button can get stuck or break completely. This guide will show how to remove the button from the printer.

### TOOLS:

- [iFixit Opening Tools \(1\)](#)

## Step 1 — Power Button



- Locate the power button on the bottom left side of the device.
- Wedge the opening tool into the small gap between the power button panel and printer.
- Apply pressure on the opening tool and open the power button panel.
- Gently remove the power button panel assembly from the printer to access the power button.

## Step 2



- Press on the power button from the front of the panel to release it.

## Step 3



- Turn the panel around so you are viewing the back of it.
- Disconnect the power button from the panel by gently pulling the button out (toward your body).

***(i)*** Be careful not to crack the connector of the button panel when pulling the power button

To reassemble your device, follow these instructions in reverse order.