



# HP Omen 15-ax243dx Battery Replacement

Battery draining quickly and not getting enough time on a charge to do your work? Follow this guide on how to replace your battery.

Written By: vangnam



## INTRODUCTION

Is your battery dying often? Does it not hold charge or even not charge at all? Well maybe it's time to replace your battery and with this guide you can replace it with only 4 simple steps taking 5-10 minutes of your time. The only tool you will need is the standard #00 Phillips Screw-driver in order for you to remove the appropriate screws. Follow this guide to successfully remove the battery from your HP-Omen laptop.

### TOOLS:

- [iFixit Opening Tools \(1\)](#)
- [Phillips #00 Screwdriver \(1\)](#)


## Step 1 — Battery



- The rear panel is secured by 10 screws. Using a #00 Phillips Screwdriver, remove the ten 1.2 mm screws.
- The screwdriver should be inserted at the same angle as the screws.

***ⓘ Be sure to keep track of the screws and where they came from. Some only fit in to one spot.***


## Step 2



- Insert the plastic opening tool between the rear panel and the top casing. Gently push the opening tool upwards to remove the bottom case.
- Follow your hand behind the tool and lift the case up gently.


! If too much pressure and force is applied, you could crack one of the panels.

## Step 3



- Remove the four 1.2 mm Phillips #00 screws around the battery.

## Step 4



- Pull the cable out to disconnect the battery from the device. The battery will lift straight out of the device.
- Disconnect the cord from the battery and dispose of the battery if needed.

To reassemble your device, follow these instructions in reverse order.