



HP Pavilion 15-cc123cl Back Cover Replacement

Use this guide to remove the back cover in your HP Pavilion 15-cc123cl.

Written By: Justin Ogihara



INTRODUCTION


Prerequisite only guide.



TOOLS:



- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Back Cover



- i Make sure to power off the laptop before proceeding with the guide.
- Turn the laptop over so the back is facing up. Use a Phillips #0 screwdriver to remove the 11 screws from the bottom cover. Rotate the screws counter-clockwise.
 - Eight 5mm screws.
 - Three 10mm screws.

Step 2



- Gently remove the CD-ROM drive by using a plastic opening tool and sliding it out of the laptop housing.
- Using the opening tool, gently pry open the back panel of the laptop. Slowly work around the edge of the laptop with gentle pressure.
- Remove the back cover from the laptop.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-04-06 07:15:15 AM (MST).

