



HP Pavilion 17-e117dx Battery Replacement

This guide will assist the reader to successfully remove, and replace the battery.

Written By: Youki Kuwahara



INTRODUCTION


Before attempting to remove the battery from the HP Pavilion 17-e117dx, make sure that it is powered off and nothing is plugged into the laptop. Also, make sure your hands are clean and dry. You will not need any tools for this procedure.

Step 1 — Battery



- Turn the laptop upside down, so that the bottom is facing up.

Step 2



- Slide the battery release latch to the left. The battery will pop up slightly.
- Lift the battery upwards and out of the laptop.

To reassemble your device, follow these instructions in reverse order.