



# HP Pavilion G6-1d16dx Hard Drive Replacement

This guide outlines how to replace the hard drive.

Written By: Shyanne Bolton

## INTRODUCTION


This guide outlines how to replace the hard drive. Replacing the hard drive is a simple process, and this guide describes that process. While there may not be pictures, there is a high quality step-by-step guide all focused on replacing your hard drive.

## Step 1 — Battery



- Flip the computer so that the bottom side is facing up, and locate the battery above the screen hinges.

## Step 2



- Slide the switch under the battery compartment to release the battery.

## Step 3



- The battery will pop out above the latch; now remove the battery.

## Step 4 — Hard Drive



- Unscrew the two silver screws holding the protective cover in place.
- The screws do not detach from the cover.
- Remove Cover by lifting the edge along the battery compartment.

## Step 5



- Slide the hard drive towards the empty gap, lift up on the hard drive, and remove it.
- ⓘ If the replacement hard drive lacks a rubber case- remove the rubber case that is around the old hard drive, and place it over the new hard drive.

## Step 6



- Re-insert the hard drive, and slide it back into place.

To reassemble your device, follow these instructions in reverse order.