



HP Pavilion G60-247CL RAM Replacement

Many laptop issues trace back to a faulty RAM card. Luckily your memory is fairly easy to replace, just follow this guide!

Written By: Zachary Herrera



 **TOOLS:**

- [Phillips #1 Screwdriver](#) (1)
- [Spudger](#) (1)

Step 1 — Battery



- Press down and to the right on the battery lock slide.
- Once slid over to the right the battery will pop up and out.

Step 2 — RAM



- Locate RAM access door on the bottom side of the laptop.

Step 3




- Locate the two screws holding down the RAM access door.
- Unscrew the two screws with a size #1 Phillips screwdriver.

Step 4



- Lift up on the RAM cover and remove it to reveal RAM sticks.

Step 5



- Gently pull apart the two metal tabs located on both sides of the stick of RAM.

Step 6



- Gently lift the RAM stick up and out of its seat.

Step 7



- Repeat the previous two steps for the remaining stick of RAM.

To reassemble your device, follow these instructions in reverse order.