



# HP Pavilion G7-2289wm RAM Replacement

This guide provides instruction on how to replace the RAM module.

Written By: Ryson Smith



## INTRODUCTION

This guide provides instruction on how to replace the RAM module.

### TOOLS:


- Phillips #0 Screwdriver (1)

## Step 1 — Battery




- Slide the battery release latch to the left, towards the center of the laptop.
- Lift the battery up, and pull towards the center of the laptop to remove it.

## Step 2 — RAM



- Loosen the screw that secures the service cover.
- Pull the service cover towards you to remove it.

## Step 3



- Unlock the tabs on each side of the ram module. (this lifts the ram module up)

## Step 4



- Remove the ram module by pulling it gently away from the slot.

To reassemble your device, follow these instructions in reverse order.