




HP Pavilion dm4-2015dx RAM Replacement

This guide will show the user how to replace the RAM sticks.

Written By: Jacob Meloche



 **TOOLS:**


- Mako Driver Kit - 64 Precision Bits (1)

Step 1 — RAM



- Locate the and remove the battery from device.

Step 2



- Remove 2 screws securing the cover (as shown in pic)

Step 3



- Locate and remove RAM carefully without breaking anything.

Step 4



- Insert the new RAM inside the same slot the older one was taken out of and put the cover back in place.

To reassemble your device, follow these instructions in reverse order.