




HP Pavilion dv6500 RAM Card Replacement

This guide will help you replace the RAM cards for the laptop in the case they are damaged or you wish to upgrade them.

Written By: Andrew



INTRODUCTION

In this guide, we will explain in a few short steps the process that will need to be taken in order to replace either of the RAM cards inserted in the laptop.

TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [Phillips #00 Screwdriver](#) (1)

Step 1 — Battery



- Flip computer face down.


Step 2



- Remove the battery by sliding the button to the side.

⚠ Be careful if the battery is leaking or appears punctured in anyway. Battery acid is harmful and may cause burns.

Step 3 — Back Panel



- Remove fifteen 7.0mm PH0 screws.
- Remove five silver 4.0mm PH 0 screws inside the cavity for the battery.

Step 4 — RAM Card



- Using your fingers or thin non metallic tweezers, pull the 2 silver levers on either side of the RAM card outward to until the ends pop up.
- Slide the RAM cards out of their sockets.

To reassemble your device, follow these instructions in reverse order.