




# HP Pavilion dv7t-7000 RAM Replacement

This is a RAM replacement for HP Pavilion dv7t-7000

Written By: Afnan



## INTRODUCTION

This is a RAM replacement for HP Pavilion dv7t-7000.

### TOOLS:


- [Phillips #00 Screwdriver](#) (1)

## Step 1 — Battery




- Turn the computer off and disconnect it from all power sources.

## Step 2



- Slide the battery release switch to the left.

## Step 3



- Hold the release switch all of the way to the left and your other hand to pull the battery out.


## Step 4 — Back Panel



- Unscrew the single Phillips #00 screw.

**i** Screw will not come out, it is connected to the panel

## Step 5




- Remove service hatch by sliding away from the computer and lifting up.

## Step 6 — RAM



- Push the restraining springs away from the RAM at the same time to unlock the RAM.

## Step 7



- Pull the RAM out.
- Follow the same procedure for the additional RAM.

To reassemble your device, follow these instructions in reverse order.